

Setup an Exchange email account – LG P500 Optimus One


On the handset

1. From the home screen, tap on the **Applications launcher** icon.




Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

2. Tap on the **Email** icon.





3. Tap **MS Exchange**.




Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

4. Enter your Email address.


5. Tap on the **Password** field.

Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

6. Enter your password.




7. Tap **Next**.




Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

8. Check and edit (if required) the already populated **Domain\Username** and **Exchange Server** field.




9. Ensure that the **Use secure connection** check box is ticked.




10. Tap **Next**.

Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

11. Wait while the device checks server settings.




12. Tap on **Email checking frequency** field arrow.




Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

13. Set the desired email checking frequency (i.e. **Automatic**)




14. Ensure that the **Send email from this account by default** field's check box is ticked.




15. Tap **Next**.

Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.

16. Enter a name for this account, then tap **Done**.



17. Press the **Home key** to return to the home screen.



Disclaimer: Whilst all reasonable care has been taken in the preparation of this information, software updates and other such items after the time of publication may impact the accuracy of the information contained within this document.